



Braillewriter Practice

Laurel J. Hudson, PhD

Putting Paper in Braillewriter:

1. Find a position so the keys are lower than your elbows.
2. Press down the line spacing key until it's firm.
3. Check the margin stop on the left.
4. Check the margin stop on the right.
5. Bring the embossing head to the far left.
6. Bring either paper release lever toward yourself.
7. Start to feed in the paper, sliding it toward yourself and under the embossing head and the left paper stop.
8. Bring either paper release lever away from yourself to lock the paper in.
9. Roll in the paper with either or both paper feed knobs until it doesn't go further.
10. Press the line space (or down space) one time.

Writing, and Taking Paper out of Braillewriter:

11. Press key 1, space, key 2, space, key 3, space, key 4, space, key 5, space, key 6 space.
12. Bring the embossing head to the far left and press the line space one time.
13. Press key 6, then key 5, then key 4, then key 3, then key 2, then key 1, with no spaces in between.
14. Backspace 6 times until the embossing head is over the first cell in this line and press all 6 cells at the same time ("full cell") 6 times.
15. Press space bar one time, and feel how you have "covered" what you wrote on this line.
16. Press the line spacing key (down space key) until it's firm.
17. Hold the paper with one hand, bring either paper release lever toward yourself, and take out the paper.
18. Bring the embossing head to the far right so the spring inside the braillewriter is expanded. CONGRATULATIONS!